D^{med®} triango 30 C Spec Sheet D15-170-110 DERUNGS 500MM



Ele	ctrical:				
Nominal input voltage		100-120V / 200-240V			
Frequency range		50 / 60Hz			
Power consumption		30W (42-52VA)			
Input current		0.42A			
Integrated electronic transformer		24V DC output			
Approval - Safety		ETL/cETL			
User interface			Continuously dimmable rot	tary switch on the head	
Illumination:			I		
Fitted with		LED Technology	30		
	Central illuminance at 1.0m		55,000 lux E(x)		
Light field diameter d10 at 1.0m		$\emptyset = 16 \text{ cm } (6.3 \text{ in})$			
Light field diameter d50 at 1.0m		$\emptyset = 8.5 \text{ cm} (3.3 \text{in})$			
Depth of illumination L1 + L2		120cm (47.24in)			
Color Temperature		4500 K 5			
Color Rendering Index Ra		>95			
Life time		30000h			
Weight:					
Light head		3 kg (6.6lbs)			
triango 30 C (includes light head)			15 kg (33lbs)		
triango 30 F (includes light head)		15 kg (33lbs)			
Luminaire Materials		Head – polycarbonate & acrylonitrile butadiene styrene copolymer (PC & ABS); Arm – metal			
Fastening		Ceiling mount to structural ceiling, tube can be field cut to length (150-500 mm)			
Classification:					
triango 30		Class I; FDA Class II			
Degree of protection as per IEC 529		IP 20			
Light head		IP 43 (horizontal position)			
Electrical safety test according to:		AAMI ES60601-1, CSA C22.2#60601-1, IEC/EN 60601-1, IEC/EN 60601-2-41, IEC/EN 60601-1-2			
Special feature		Removable Sterilizable Handle included			
	mponent List - II				
#	Part Number	Description	<u></u>	- ////////////////////////////////////	
1	US4-001-205	Mounting Adapter 13		Measurements in cm	
2	Call Factory	Mounting Plate 13.3 in.		3	
3	US4-001-400	Dome Cover			
4	US4-001-500	Collar, 2 piece with screws		- 5	
5	US4-001-310	Pole, 500MM Length		45° - 360° - 38	
6	D74-544-100	Spring Balanced Arm			
7 D15-353-000 Head, Triango 30, 24		V, LED			
Additional Information Available (Manuals)			300 7		
1	Call Factory Triango Pre-Install Gui		uide		
2	2 Included Triango Manual			NOTE: If fixture is to be installed above a drop ceiling, Additional items 3 and 4 must be ordered separately.	
3	3 Call Factory Triango Spare Parts M		Manual	Please refer to Triango Pre-Install Guide for installation suggestions.	